

PC Diagnostics



Software
246 301 5 . . 0

Interface-Set
[incl. Cable to PC]
446 301 021 0 (COM)
446 301 022 0 (USB)

Diagnostic-Cable
446 300 329 2

Couplings



Supply
952 201 002 0



Brake
952 201 001 0

Data/Info Plates

System plate
899 200 922 4



Sticker



813 000 008 3

if wear indicators fitted



813 000 025 3



Dual Circuit
463 084 010 0

Single Circuit
463 084 030 0

Lift Axle Control Valve



Standard 4S/2M **480 102 010 0 (2S/2M - 4S/2M)**
Premium + 4S/3M **480 102 014 0 (2S/2M - 4S/3M)**
TCE + 4S/3M **480 102 015 0 (2S/2M - 4S/3M)**

EBS Trailer Modulator



Type	Part Number
16	423 104 710 0
18	423 112 710 0
20	423 505 000 0
22	423 110 710 0
24	423 506 001 0

Brake Actuator (for disc brakes)



Type	Part Number
16/16	925 464 . . . 0
16/24	925 464 . . . 0
18/24	925 463 . . . 0
20/24	925 460 . . . 0
24/24	925 461 . . . 0

Springbrake Actuator (for disc brakes)

Park Release Emergency Valve



PREV
971 002 900 0

Reservoir



	Part Number	Capacity (Litres)	Diameter (mm)
	950 560 001 0	60	246 mm
	950 760 002 0	60	276 mm
	950 060 003 0	60	310 mm
Drain Valve	950 060 004 0	60	396 mm
	950 080 002 0	80	396 mm

Drain Valve
934 300 001 0

Reservoir Mounting Strap



Diameter (mm)	Part Number
246 mm	451 999 246 2
276 mm	451 999 276 2
310 mm	451 999 310 2
396 mm	451 999 396 2

Sensor & Cable / Sensor Bush



Sensor kit
(Sensor + bush + grease)

Cable Length	Part Number
0.4 m	441 032 921 2
1.0 m	441 032 922 2

Wear indicator




Wear Indicator Set
(2 Indicators / Set)
12 999 . . .



973 011 201 0

Relay Valve



Semi-trailer with Single Lift Axle and D Series EBS

Pneumatic system and Components

